

MULTIPARVA 3.0 F



High energy efficiency
Minimal polluting emissions
Climate control

**Gas condensing boiler
with stainless steel exchanger**



User manual



Dear Client,

Thank you for purchasing this condensing appliance, a technically advanced and high quality product, offering high efficiency and extremely low pollutant emissions and therefore complete respect of the environment, designed to meet all your needs for comfort at low operating costs.

Please read this manual with care before using the appliance, and observe in particular all WARNINGS and SAFETY REGULATIONS.

We also recommend that the appliance is inspected by Technical Service personnel, specially trained in servicing this type of appliance using exclusively original spare parts when necessary.

This manual is an integral part of the appliance and as such must be conserved with care for future consultation or transfer to another Owner or User.

Kind regards,

Company Management

WARRANTY

MULTIPARVA 3.0 F appliances are covered by a SPECIAL WARRANTY as of the date of authorisation by the Technical Services departments.

On delivery, the adhesive labels with bar codes supplied in the document envelope should be attached to the specific certificates.

CONFORMITY

The **MULTIPARVA 3.0 F** appliances comply with:

- Regulation GAR (UE) 2016/426
- Ecodesign directive 09/125/CE
- Ecolabel directive 10/30/CE
- Low voltage directive 2014/35/UE
- Electromagnetic compatibility directive 2014/30/UE
- Class of Seasonal energy efficiency in central heating mode A
- "Condensing" classification
- NOx Class 6 (< 56 mg/kWh)



For the serial number and year of manufacturer, refer to the technical data plate.

Company Management

The appliance must be installed by qualified personnel in conformity with current Technical Standards and national and/or local legislation.

All safety, installation and maintenance instructions must also be strictly observed, as stated in this manual.

INDEX


SAFETY WARNINGS AND REGULATIONS	4
PROHIBITED ACTIONS	4
DESCRIPTION	5
DEVICES	5
CONTROL PANEL	6
IGNITION AND SHUTDOWN	9
MENU NAVIGATION TREES AND PROCEDURES	10
SELECT LANGUAGE	13
SCHEDULER SETTINGS	14
TEMPORARY SHUTDOWN OR HOLIDAY SCHEDULE	16
MAINTENANCE	18
ROUTINE CLEANING	18
TECHNICAL INFORMATIONS	19
END OF LIFE DISPOSAL	20



SAFETY WARNINGS AND REGULATIONS

- After unpacking the appliance, ensure that all parts are intact and complete as per the supply specifications, and if any non-conformities are found, contact the Representative that sold the appliance.
- The appliance must be installed by professionally qualified personnel, in conformity with current national and local standards and the instructions in the manual supplied with the product.
- The appliance must only be used as envisaged in the design. The manufacturer declines all liability for physical injury or damage to animals or objects caused by errors in installation, adjustments, maintenance or improper use of the appliance.
- In the event of water leakage, disconnect the appliance from the electric power mains, shut off the water supply and promptly notify the Technical Services department or other professionally qualified personnel.
- Periodically check that the hydraulic system operating pressure, in cool conditions, is approx. 2 bar. Otherwise contact the Technical Services department or other professionally qualified personnel.
- In the event of prolonged disuse of the appliance, the following procedure must be observed:
 - Set the appliance switch H and the main system switch to "OFF".
 - Shut off the fuel and mains water valves.
- This manual is an integral part of the appliance and consequently must ALWAYS accompany the appliance, also in the event of sale to another Owner or User or transfer to another system. The manual must be kept with care and in the event of damage or loss, another copy may be requested from the Technical Services department.
- **It is recommended to service the appliance at least once a year.**

Pursuant to Directive 2012/19 / EU on waste electrical and electronic equipment (WEEE) "the crossed bin symbol on the appliance and on the packaging indicates that the gas boiler, at the time of its disposal, must be collected and disposed separately from other waste (see section End of life disposal).



PROHIBITED ACTIONS

- **IT IS STRICTLY PROHIBITED** to allow children or disabled persons to change settings on the appliance without assistance.
- **IT IS STRICTLY PROHIBITED** to activate electrical devices or equipment such as switches, telephones, household appliances etc. if smells of fuel or uncombusted fuel are detected. In this case:
 - Open doors and windows to ventilate the room.
 - Close the fuel shut-off valve.
 - Arrange for prompt intervention of the Technical Services or other professionally qualified personnel.
- **IT IS STRICTLY PROHIBITED** to touch the appliance with bare feet or wet parts of the body.
- **IT IS STRICTLY PROHIBITED** to perform technical interventions or cleaning before disconnecting the appliance from the electrical power mains and setting the main system switch and appliance Ⓢ switch to "OFF".
- **IT IS STRICTLY PROHIBITED** to modify safety devices or control devices without prior authorisation and instructions from the appliance manufacturer.
- **IT IS STRICTLY PROHIBITED** to pull, detach, or twist cables coming out of the appliance, even when disconnected from the electrical power mains.
- **IT IS STRICTLY PROHIBITED** to seal off or partially obstruct the ventilation outlets of the installation room and the appliance (if present). The ventilation outlets are essential to ensure efficient combustion.
- **IT IS STRICTLY PROHIBITED** to obstruct the condensate drain outlet.
- **IT IS STRICTLY PROHIBITED** to leave containers of flammable substances in the same room as the appliance.
- **IT IS STRICTLY PROHIBITED** to dispose of packaging into the environment as this constitutes a potential source of danger. It must therefore be disposed of in accordance with current legislation in the place of use.

DESCRIPTION

The aluminium boilers in the range **MULTIPARVA 3.0 F** are condensing heat generators, designed to heat rooms, and in combination with a storage tank, for the production of domestic hot water.

They comprise:

- a steel heat exchanger, with low water content and generously sized exchange surface to optimise energy efficiency and heating output;
- a full pre-mix microflame burner in stainless steel, to guarantee high modulation ratios, combustion stability and low pollutant emissions (NOx Class = 6);
- a variable speed blower, required for air/gas modulation and mixing;
- a combustion circuit, which can be “type C” (room-sealed) or “type B” (open-flued), with respect to the installation environment, and on the basis of the flue exhaust configuration on site;
- command-control electronics, which if equipped with outside sensor enables adjustment of the supply temperature on the basis of the outside temperature. The appliance thus only provides the heat effectively needed by the utility, avoiding energy waste. The unit is fitted with self-diagnostics with a display of the error codes and operating parameters at the time of the fault, thereby simplifying tasks for the Technical Services department.

Also, during periods of prolonged disuse or holidays, the appliance remains protected by the Anti-freeze Function, which is activated automatically when the supply temperature falls to 5°C and shuts off when it returns to 15°C. Obviously the gas and electrical mains supplies must be active during these periods.

The design phase adopted specific solutions to:

- obtain a constantly optimal air/gas mix;
- minimise dispersions;
- reduce noise levels to a minimum.

The **MULTIPARVA 3.0 F** boilers are designed for connection to 0-10 V DC controls and for operation in cascade, in sets of up to 6 units, and can be equipped with various system accessories, such as the mix bottle or water shut-off valve, and the INAIL unit, which all simplify the work of the installer and comply with compulsory Italian legal requirements.

The MULTIPARVA 3.0 F boilers are equipped with 5 litres expansion vessel, safety drain valve and water pump.

The MULTIPARVA 3.0 N boilers are without expansion vessel, safety drain valve and water pump.

DEVICES

MULTIPARVA 3.0 F appliances are equipped with the following safety, control and adjustment devices:


- Sensor on the appliance heat exchanger, to ensure thermal cut-out when the temperature reading exceeds the maximum admissible value. This is reset manually via the DSP keypad.
- Water pressure sensor: this intervenes when the hydraulic circuit pressure falls below 0.5 bar.
- Flue safety sensor: this intervenes when the flue temperature is too high.
- Hydraulic circuit diagnostics to protect the boiler against:
 - temperature overload, by checking the difference in temperatures on supply and return (ΔT);
 - inadequate water circulation in the heat exchanger, checking the difference in temperatures between the heat exchanger sensor and supply sensor.
- Siphon pressure switch that turn off the burner when the pressure inside the combustion chamber overcome 700 Pa.
- Air Pressure Switch (APS) (Only 150kW model) which checks the correct working of the combustion circuit before the starting of the boiler.

WARNING


- If a safety devices trips, this means that there is a potentially hazardous appliance malfunction. In this case contact Technical Services as soon as possible for assistance.

CONTROL PANEL

DSP






















DESCRIPTION OF SYMBOLS ON DISPLAY





Key functions

Key	Description of function	Display
	<p>ON/STAND-BY</p> <p>STAND-BY: This shuts down the appliance, inhibiting the use of DSP keys</p> <p>ON: This enables start-up of the appliance, enabling use of DSP keys</p>	

Key	Description of function	Display
	<p>OPERATING MODES</p> <p>SUMMER: DHW production only</p> <p>WINTER: heating only or heating and DHW</p> <p>NONE: no heating or DHW Anti-freeze or “Manual Test” function active</p>	
	<p>ECO - Manual</p> <p>This reduces, by the set value, the temperature of domestic water supply and heating water (energy saving mode)</p>	
	<p>ESC</p> <p>Interrupts the current action and returns to the initial screen</p>	
	<p>MENU</p> <p>Enables display of the page for menu selection (USER or TECHNICIAN)</p>	

Key	Description of function	Display
	<p>HOLIDAY</p> <p>This enables entry of the holiday dates (start/end) and values for the supply of domestic hot water and heating water during this period</p>	
 	<p>UP</p> <p>Enables the user to scroll up through the lines on screen</p> <p>DOWN</p> <p>Enables the user to scroll down through the lines on screen</p> <p>Keep pressed to speed up the scrolling action.</p>	
	<p>OK</p> <p>Enables:</p> <ul style="list-style-type: none"> - access to the selected line of the menu or sub-menu - confirmation of a newly modified value 	
	<p>RED (at top)</p> <p>Enables:</p> <ul style="list-style-type: none"> - access to the USER menu - increases to the value to be modified <p>Keep pressed to speed up the action.</p>	
	<p>RED (intermediate)</p> <p>Enables:</p> <ul style="list-style-type: none"> - access to the TECHNICIAN menu - decreases to the value to be modified <p>Keep pressed to speed up the action.</p>	

Key	Description of function	Display
	RED (at bottom) Enables return to the selected line without saving/storing the modified data.	


IGNITION AND SHUTDOWN


The initial commissioning of the appliance must be performed by the Technical Services, after which the appliance can operate automatically.


The system supervisor can turn the appliance on and off as follows:

INITIAL COMMISSIONING

- Power up the boiler from the electrical mains by setting the main system switch (IG) to "ON".




- The display returns to the stand-by screen.
- Press  to activate the keypad for the DSP.



MENU NAVIGATION TREES AND PROCEDURES

User menu navigation TREE and procedure

The appliance is supplied in the configuration STAND-BY.
To scroll through the screen menus, use the keys shown in the diagram below.





USER MENU	Keys	Sub-menu	Keys	Lines	Keys	Factory settings	Field	
1. HEATING		1. CH temperature/OTC set		1. CH temperature		75°C	20 - max. absolute T. (*)	
			2. Outside temperature for CH off		OFF	OFF / 7 - 30°C		
			2. ECO setpoint reduction		--->	--->	50°C	0 - 50°C
			3. Scheduler set		1. Enable/disable scheduler		Enabled	Enabled / disabled
					2. Scheduler settings		Monday	week days
2. DOMESTIC HOT WATER		1. DHW setpoint		--->	--->	80°C (**)	35 - 85°C	
			2. ECO setpoint reduction		--->	--->	20°C	0 - 50°C
			3. Scheduler set		1. Enable/disable scheduler		Enabled	Enabled / disabled
				2. Scheduler settings		Monday	week days	
		3. HOLIDAY		1. CH holiday setpoint		--->	--->	20°C
			2. DHW holiday setpoint		--->	--->	80°C (**)	30 - 85°C
4. MAINTENANCE		1. Service information		--->	--->	read only		
			2. Service due date		--->	--->	read only	
5. SETTINGS		1. Select Language		English / Italiano		Italiano	English / Italiano	
			2. Select Units		Fahrenheit / Celsius		Celsius	Fahrenheit / Celsius
			3. Set date		--->	--->	day / month / year	
			4. Set time		24 hour / 12 hour		hours : minutes	
			5. Restore factory settings		--->	--->	OK to reset	
6. DIAGNOSTICS		1. Boiler information		Read-only display of boiler status, temperature readings and blower rpm				
		2. Lockout history		read-only display of lockout/fault history				

(*) Maximum absolute temperature set at point "1.2.1" of the technician menu.















(**) - If "2.5 TYPE OF REQUEST" of the Technician menu = "Contact" then "Factory setting" = 80°C with "Field" = 30 ÷ 85°C.

- If "2.5 TYPE OF REQUEST" of the Technician menu = "Sensor" then "Factory setting" = 60°C with "Field" = 10 ÷ 65°C.

Key to the USER menu LINES

Ref. menu line	Line title	Meaning
1. HEATING		
1.1.1	CH temperature/OTC set	Entry of setpoint of supply temperature (heating)
1.1.2	Outside temperature for CH off	Entry of setpoint of outside temperature for automatic switchover to "Summer mode"
1.2	ECO setpoint reduction	Entry of value to reduce temperature on supply in "energy saving" mode (day or night time)
1.3.1	Enable/disable on board scheduler	Enable or Disable implementation of the "heating time bands" set for the various week days
1.3.2	Scheduler set	Settings of the "heating time bands" applied for the various week days
2. DOMESTIC HOT WATER		
2.1	DHW setpoint	Entry of the setpoint for DHW temperature
2.2	ECO setpoint reduction	Entry of value to reduce temperature of DHW in "energy saving" mode (day or night time)
2.3.1	Enable/disable on board scheduler	Enable or Disable implementation of the "DHW production time bands" set for the various week days
2.3.2	Scheduler set	Settings of the "DHW production time bands" applied for the various week days
3. HOLIDAY		
3.1	CH holiday setpoint	Entry of the setpoint for supply temperature during the holiday period.
3.2	Instant DHW setpoint	Entry of the setpoint for DHW during the holiday period.
4. MAINTENANCE		
4.1	Contact info	Display of services contact phone number
4.2	Service due date	Display of date for next maintenance due
5. SETTINGS		
5.1	Select Language	Selection of language (English or Italian)
5.2	Select Units	Selection of units of measurement (Celsius or Fahrenheit)
5.3	Set date	Entry or modification of current date. The transition from DST to the Solar time will take automatically.
5.4	Set time	Selection of 12 or 24 hour format - Entry or modification of current time
5.5	Restore factory settings	Restores factory settings
6. DIAGNOSTICS		
6.1	Boiler information	Display of boiler status and temperature readings To display, select the message, press OK and view the values, scrolling through items by means of the arrows  
6.2	Lockout history	Display of the error list.























SELECT LANGUAGE
























Key	Description of function	Display
 	<p>to display the MENU screens</p> <p>to enter the USER MENU</p>	
 4 TIMES 	<p>to select "5. SETTING"</p> <p>to confirm and access the selected line</p>	
	<p>to confirm and access the "LANGUAGE" line</p>	
  	<p>to select the desired language</p> <p>to confirm the language e to return at the previous menu</p>	
	<p>to come back at the initial screen.</p>	

SCHEDULER SETTINGS

The system also envisages the option of setting time bands during which the boiler is set to operate, if there is a demand for heat, and those during which it remains off, or in ECO mode when fitted with an outside sensor.

There is a maximum of 6 programmable time bands within 24 hours, each of which must be identified by a start time (ON), and end time (OFF). The minimum interval between each time is half an hour.

Key	Description of function	Display
 	<p>to display the MENU screens</p> <p>to enter the USER MENU</p>	 
  	<p>to select "1. HEATING"</p> <p>or</p> <p>to select "2. DOMESTIC HOT WATER"</p> <p>NOTE: the scheduler setting procedure is the same for both functions.</p>	 
 2 VOLTE 	<p>to select "3. Scheduler set"</p> <p>to confirm and access the selected line</p>	 
  	<p>to select Enabled or Disabled</p> <p>to confirm the selection and return to line "1. Enable/disable on board scheduler"</p> <p>CAUTION: if the selection is DISABLED, the scheduler settings are memorised but not enabled.</p>	 
 	<p>to select "2. Scheduler set"</p> <p>to confirm and access the selected line</p>	 

Key	Description of function	Display
  	<p>to select the single day or group of days in the week</p> <p>to confirm and access the selected line</p>	 
    	<p>to set the “start” time of the first band</p> <p>to set the “end” time of the first band</p> <p>to select the operating mode of the first time band, from ON, ECO or -- (boiler OFF)</p> <p>to go to the second time band To enter the settings, proceed in the same way as with the first band.</p> <p>NOTE: the time entry procedure is the same for all selected time bands.</p>	   
 	<p>to select “Save and exit” or “Copy to the Next Day” (if the user wishes to copy the current settings to the next day)</p> <p>to save the settings made and return to the line of the single day or group of week days selected previously</p>	 
  	<p>to select the day or days remaining and set the required time bands</p> <p>to confirm and access the selected line</p> <p>NOTE: the time entry procedure is the same for all selected time bands.</p>	 






















TEMPORARY SHUTDOWN OR HOLIDAY SCHEDULE

This function enables a reduction in the operating regime of the boiler in the case of temporary absences, weekends, holidays and above all automatic restart after the set time interval.

















WARNINGS

- During the holiday period, it is essential to leave the electrical and gas mains supplies to the appliance powered, to ensure correct operation.

The supply temperatures for the heating system and/or production of domestic hot water, must be set as described below:

Key to press	Description	Display
 	<p>to display the MENU screens</p> <p>to enter the USER MENU</p>	 
 2 VOLTE 	<p>to select "3. HOLIDAY"</p> <p>to confirm and access the selected line</p>	 
   	<p>to select "1. CH holiday setpoint"</p> <p>to set the required value</p> <p>to confirm the settings and return to line "1. CH holiday setpoint"</p>	 
    	<p>to select "2. DHW holiday setpoint"</p> <p>to confirm and access the selected line</p> <p>to set the required value (only in the case of storage tanks with sensor) (*)</p> <p>to confirm the settings and return to line "2. DHW holiday setpoint"</p>	 

(*) In the case of storage tanks with thermostat, take care not to set an excessively low value, as this could cause continuous requests for domestic hot water.

Key to press	Description	Display
	to return to the initial screen	
	to display the "Holiday start" date	
	to set the holiday start day	
	to select the month	
	to select the year	
	to set the month	
	to select the year	
	to set the year	
	to set the year	
	to confirm the settings made and enter the "Holiday end" screen.	
	<p>NOTE: to make the settings for the day, month and year of the holiday end, follow the same procedure as described for "Holiday start".</p>	

MAINTENANCE

Note that it is a **COMPULSORY LEGAL REQUIREMENT THAT THE BOILER SUPERVISOR must arrange for PERIODIC MAINTENANCE and COMBUSTION EFFICIENCY MEASUREMENTS to be performed by PROFESSIONALLY QUALIFIED PERSONNEL.**

The Technical Services department can fulfil this legal requirement when necessary.

PERIODIC MAINTENANCE guarantees:

- Increased safety
- Reduced operating costs
- Extended lifetime of the boiler
- The reassurance of not receiving considerable penalties in the event of inspections.

ROUTINE CLEANING

Internal cleaning of the appliance and removal of combustion residue from the exchange surfaces are operations required **at least once a year**, to be performed by professionally qualified personnel.

This is an essential condition to reduce consumption, pollutant emissions and to keep the stated efficiency and reliability of the boiler over time.


Before cleaning:

- Set the main system switch (IG) to "OFF"
- Close the fuel shut-off valves.

EXTERNAL CLEANING

The outer casing should be cleaned with cloths dampened with water and detergent. In the case of stubborn stains, dampen a cloth with a mix of 50% water and denatured alcohol or with special products.

After cleaning, dry the appliance thoroughly.



WARNINGS

- Never use abrasive products, benzene or trichloroethane

Technical informations compliance Reg. 813/2013 All.II point 5

Description:	Symbol	U.M.	MULTIPARVA 3.0 F			
			M156HE.95/F	M157HE.110/F	M158HE.115/F	M158HE.150/F
Condensing boiler:			Si			
Low-temperature boiler:			No			
B1 boiler:			No			
Cogeneration space heater:			No			
Combination heater:			No			
Rated heat output	P_{nominale}	kW	95	115	115	150
Useful heat output						
Rated power high-temperature regime	P4	kW	93	112	112	146
At 30 % of rated heat output and low-temperature regime	P1	kW	31	37,4	37,3	48,7
Seasonal space heating energy efficiency	η_s	%	93	93	93	93
At rated heat output and high-temperature regime	η_4	%	87,8	87,5	87,6	87,6
At 30 % of rated heat output and low-temperature regime	η_1	%	97,9	97,6	97,4	97,5
Auxiliary electricity consumption						
At full load	Elmax	kW	0,174	0,190	0,158	0,281
At part load	Elmin	kW	0,022	0,019	0,024	0,025
In standby mode	PSB	kW	0,003	0,003	0,004	0,004
Standby heat loss	Pstby	kW	0,100	0,112	0,141	0,141
Ignition burner power consumption	Pign	kW	0	0	0	0
Emissions of nitrogen oxides	NOx	mg/kWh	43	32	29	47

END OF LIFE DISPOSAL

Outdated appliances

When you decide to permanently shutdown the boiler, please request a qualified professional to decommission the boiler & ancillary equipment. They must ensure that boiler has been disconnected from power supplies, water and gas.

This device contains potentially recyclable materials that can be reused. Components are easy to separate and for this reason, they can be processed and used for recycling or disposal.

- Electrical and electronic components no longer usable must be collected separately and recycled in an environmentally friendly way.
- Do not dispose of either the product or the accessories with household waste. Make sure that products and all accessories are disposed of in a workmanlike manner.
- Always observe all laws in force.

Attention

Gas boilers are electrical and electronic appliances (AEE) and, when dismissed, they become electrical and electronic waste (RAEE): as such, they must be disposed according to current legislation.

Gas boilers are classified as household appliances and must be disposed with washing machines, dishwashers and dryers (RAEE R2 waste).

The disassembly of gas boilers and their disposal through channels not approved is prohibited by law.

The user has the right to be able to deliver the disused gas boiler, integral in its construction, to the ecological area.

The installer and the user have the right to be able to deliver the disused gas boiler, integrated in its construction to the point of sale where they purchase the new gas boiler.

Packing

With regards to packaging; BIASI always use recyclable and ecological components.

All materials used for packaging are environmentally friendly and can be reused; please follow the recycling procedures specific for your country, which guarantee optimal recycling.

- Dispose of the packaging material of the boiler in accordance with the laws for environmental protection.

NOTE

NOTE





008274462 3621 24A4 EN
17962.0297.0 3621 24A4 EN

BSG Caldaie a Gas S.p.A.

*Registered office, sales and administrative headquarters,
Plant and technical support*


Via Pravalton, 1/b – 33170 PORDENONE (Italy)

 +39 0434 238311


 +39 0434 238387

 www.biasi.it

Sales headquarters

 +39 0434 238400

Technical support

 +39 0434 238387

This manual replaces previous versions.

In order to constantly improve its products, BSG Caldaie a Gas S.p.A. reserves the right to change the data provided in this manual at any time and without notice. Product warranty pursuant to Italian Leg. Decree. no. 24/2002.